

playmobil®

family fun



70341



WARNING: CHOKING HAZARD




Contains a small ball and small parts.
Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!




Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.

1








3



4






5




2x







1




2




1



2



3




30 06 1603



30 06 1593

30 23 8420

 $2x$ 

30 25 0760

30 25 0030

2

30 08 9930

30 03 0150

30 23 1042

30 20 3030

30 23 1260


30 22 5932









2

30 07 5830

6

5





30 05 8562



30 22 2372

30 21 5063



30 63 5284



30 62 6715



30 62 6795

30 28 8760



30 28 9310

30 25 6360




30 25 6370

30 22 2212



30 20 4322

30 06 1663



30 06 1653

30 06 1853



30 00 6384

30 06 9800



30 14 3182



30 14 3192



30 00 6394

30 25 3243



30 11 4390



30 10 4670



30 06 1483



30 65 6954



30 66 7013



30 63 8676



30 46 7320




30 06 1473



30 46 7330



30 22 5622



30 06 1793



30 06 2173



2x 30 24 2833



2x 30 06 7780



30 65 0220



30 23 4183



30 65 8822



30 06 1503



2x 30 06 1533



30 82 6315



2x 30 06 1563




30 29 5330




30 02 4190



2x 30 20 9692



2x 30 06 1493



30 21 7333



30 21 0203



30 05 7542



30 20 4412




4x 30 25 6350



30 64 2184



4x 30 22 6242




30 06 1543



30 06 1573



2x 30 06 1723



30 06 1553



30 06 1713



2x 30 25 6070



30 24 8472



3x 30 25 1300



2x 30 25 0030



30 08 5670



2x 30 04 2760



30 06 1523



2x 30 09 2110



30 25 0760



30 06 1643



30 02 2112



30 07 3032



30 20 9040



30 62 1726



30 21 8573



30 62 1875



30 63 9394



3x 30 22 3443



5x 30 25 4943



5x 30 25 2810



3x 30 21 9273



4x 30 25 8720



6x 30 03 6600



2x 30 09 6900


2x




2x



30 51 9410



2x 30 51 9822



30 51 9782


70341

70341 + 



70343

70348





70348



70354



70357



70360



70358



~~70341~~



70355



70349



70356



70343



70347

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten

Addresses of Customer Service
Departments are shown in all
PLAYMOBIL catalogues

L'adresse du service
consommateurs est indiquée
dans tous les catalogues PLAYMOBIL

Troverete gli indirizzi dei centri
di assistenza in tutti i cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi
vindi u het adres van onze klantendienst.

Las Direcciones de los Departamentos
de Servicio al Consumidor se encuentran en
todos los catálogos PLAYMOBIL

Η διεύθυνση του Γραφείου
Εξυπηρέτησης Καταναλωτών
PLAYMOBIL βρίσκεται σε όλους
τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēel

